16 5/8 15 3/4 8 3/8

5/8-11 UNC TAPPED HOLE

R	EV.	DESCRIPTION	DATE	BY


TYPE M2H-3D SPRING ISOLATORS WITH INTERNAL ADJUSTMENT								
MODEL	MAX LOAD	DEFLECTION	SPRING RATE	SPRING				
	(LBS)	(IN)	(LB/IN)	COLOR CODE				
M2H-3D-1600	1600	3.00	533	DK GRAY				
M2H-3D-2450	2450	2.94	833	RED				
M2H-3D-3020	3020	2.52	1200	MED GRAY				
M2H-3D-4070	4070	2.54	1600	DK YELLOW				

(BY OTHERS, NOT SHOWN IN OTHER VIEWS FOR CLARITY) REMOVABLE ADJUSTING BOLT ADJUSTING NUT AND WASHER (NOT (NOT SHOWN IN OTHER VIEWS SHOWN IN OTHER VIEWS FOR CLARITY) FOR CLARITY) (2 TYP)-(2 TYP) - 3/8 GAP ELASTOMERIC **SNUBBER** 11 1/8 FREE AND **OPERATING HEIGHT** 1/4 RIBBED **ELASTOMERIC** PAD (2 TYP) 3/4 DIA HOLE (4 TYP) **- 3/8** 7/8 🛦 NOTES: 1. ALL DIMENSIONS ARE IN INCHES, INTERPRET PER ANSI Y14.

- BOLT OR WELD EQUIPMENT SUPPORT BEAM TO MOUNT

STEEL SHIM (2 TYP) (REMOVE AFTER SPRING ADJUSTMENT) (SHIM ON FAR SIDE NOT SHOWN FOR CLARITY)

LIMIT-STOP (4 TYP)



ISOLATOR SELECTIONS					
LOC 1:	LOC 2:				
LOC 3:	LOC 4:				
LOC 5:	LOC 6:				
LOC 7:	LOC 8:				
CUSTOMER EQP'T. TAG:	•				

NOTE: MATERIAL SHOWN IS FOR (1) SET.

2. UNLESS OTHERWISE NOTED, DIMENSIONS FOR STYLE APPLY TO ALL OTHER STYLES.

3. FINISH: HOUSINGS- POWDER COAT, SPRINGS- POWDER COAT, HARDWARE- ZINC ELECTROPLATE.

4. REFER TO SHEET 2 OF 2 FOR INSTALLATION INSTRUCTIONS.

5. INNER SPRING (WHEN USED) NOT SHOWN.

CERTIFIED FOR

SALES ORDER:

120R-101780 REV.: 6

6. ALL SPRINGS ARE DESIGNED WITH 50% OVER TRAVEL.

7. SPRING PACKAGE MAY BE REMOVED WITH SHIMS IN PLACE. CONTACT A FACTORY REPRESENTATIVE FOR SPRING REMOVAL INSTRUCTIONS.

8. DIMENSIONS APPLY TO BOTH TOP BOLT DOWN AND BASE PLATE ANCHORING HOLE.

9. RATED DEFLECTIONS ARE WITHIN 25% OF NOMINAL. HIGHER DEFLECTIONS ARE ALLOWED IF THEY MEET SPECIFICATIONS.

OTHER MATERIALS, COMPOUNDS, OR FINISHES WITH EQUAL OR SUPERIOR PROPERTIES MAY BE SUBSTITUTED AS THEY BECOME AVAILABLE.

OLIVIII ILD I OIV.				
JOB NAME:				
CUSTOMER:				
CUSTOMER P.O.:				

MODEL M2H-3D 1600-4070 LBS. SPRING ISOLATORS WITH INTERNAL ADJUSTMENT 3 INCH DEFLECTION

	SI
THE VMC GROUP The Power of Together	DF

NONE



The Power of Together
Bloomingdale, NJ 07403
Houston, TX 77041


DRAWING NO.:

NO.: REVISION

120R-101780 REV.: 6 REV. DESCRIPTION DATE BY

READ INSTRUCTIONS IN THEIR ENTIRETY BEFORE BEGINNING.

- 1. LOCATE ISOLATORS UNDER EQUIPMENT AFTER DETERMINING POSITIONS DESIGNATED IN THE VMC GROUP SUBMITTAL, SHEET 1.
- 2. ALL LIMIT BOLTS ARE FACTORY SET AND BONDED IN PLACE. THE SHIPPING NUT ON THE LIMIT BOLT MUST BE LOWERED UNTIL IT TOUCHES THE BOLT HEAD. THE NUT WAS SHIPPED IN THE RAISED POSITION. DO NOT ATTEMPT TO READJUST THE LIMIT BOLTS. FACTORY SETTING ASSURES UNIFORM BOLT LOADING IF UPLIFT OCCURS, AS IN THE CASE OF A COOLING TOWER BEING DRAINED.
- THE VMC GROUP RECOMMENDS BOLTING ALL ISOLATORS TO A FLAT SURFACE. WHEN A WEIGHT CHANGE OCCURS IN EXCESS OF 20% OF EQUIPMENT OPERATING WEIGHT, THE ISOLATOR BASE PLATE MUST BE BOLTED. STYLE "A" TOP PLATE MUST BE USED WITH A WIDE FLANGE BEAM BOLTED TO TOP PLATE AS SHOWN ON SUBMITTAL DRAWING.
- 4. WHEN THE APPLICATION IS OUTDOORS AND THE EQUIPMENT WILL BE SUBJECT TO HIGH WINDS. THE OWNER'S REPRESENTATIVE MUST EVALUATE ANCHOR TYPE AND SIZE TO EFFECTIVELY RESIST WIND FORCES. TYPE M2H ISOLATORS ARE NOT SUITABLE FOR SEISMIC APPLICATIONS. USE VMC GROUP TYPE MS ISOLATORS TO ISOLATE EQUIPMENT THAT WILL BE SUBJECT TO SEISMIC FORCES.
- 5. ISOLATORS ARE SHIPPED TO THE JOB SITE WITH SHIMS BETWEEN THE TOP PLATE AND HOUSING. THESE SHIMS MUST BE IN PLACE WHEN ISOLATOR IS POSITIONED UNDER EQUIPMENT.
- 6. THE ADJUSTMENT PROCESS CAN ONLY BEGIN AFTER FULL OPERATING WEIGHT IS REACHED. THE ADJUSTMENTS CAN BE MADE BY STARTING AT ANY ISOLATOR AND TURNING THE ADJUSTING NUT CLOCKWISE TWO TURNS. PROCEED AROUND THE EQUIPMENT TO EACH ISOLATOR ADJUSTING EACH TWO TURNS TO COMPRESS THE SPRINGS UNIFORMLY. CONTINUE THIS ADJUSTING PROCESS UNTIL ONE ISOLATOR JUST RISES OFF THE SHIMS. STOP ADJUSTMENT ON THAT AND OTHER ISOLATORS AS THEY RISE OFF SHIMS APPROXIMATELY 1/32". WHEN ALL ISOLATORS HAVE RISEN ABOVE THE SHIMS, THE ADJUSTMENT PROCESS IS COMPLETE. REMOVE ALL SHIMS.
- 7. FURTHER ATTENTION TO THE INSTALLATION IS NOT NORMALLY REQUIRED. THE VMC GROUP SUGGESTS A SEMIANNUAL INSPECTION OF THE COMPONENTS FOR POSSIBLE CORROSION PROBLEMS. IF PROBLEMS ARE OBSERVED. CONSULT THE VMC GROUP OR CORROSION CONTROL EXPERTS TO RECTIFY THE PROBLEM.
- 8. IF THE SPRING PACKAGE MUST BE REMOVED, CONTACT A FACTORY REPRESENTATIVE FOR SPRING REMOVAL INSTRUCTIONS, SHEET,



OTHER MATERIALS, COMPOUNDS, OR FINISHES WITH EQUAL OR SUPERIOR PROPERTIES MAY BE SUBSTITUTED AS THEY BECOME AVAILABLE

JOB NAME: CUSTOMER:

CUSTOMER P.O.:

SALES ORDER:

MODEL M2H-3D 1600-4070 LBS. SPRING ISOLATORS WITH INTERNAL ADJUSTMENT 3 INCH DEFLECTION



NONE SHEET:

Bloomingdale, NJ 07403 Houston, TX 77041

REVISION