

CERTIFIED FOR: JOB NAME:

CUSTOMER:

CUSTOMER P.O.:

SALES ORDER:

MODEL M2H-5C 500-4600 LBS. SPRING ISOLATORS WITH INTERNAL ADJUSTMENT **5 INCH DEFLECTION**

THE VMC GROUP
The Power of Together

NONE SHEET:

Bloomingdale, NJ 07403

DRAWING NO.: REVISION

Houston, TX 77041

120R-101796 REV.: 6 REV. DESCRIPTION DATE BY READ INSTRUCTIONS IN THEIR ENTIRETY BEFORE BEGINNING. 1. LOCATE ISOLATORS UNDER EQUIPMENT AFTER DETERMINING POSITIONS DESIGNATED IN THE VMC GROUP SUBMITTAL. SHEET 1. 2. ALL LIMIT BOLTS ARE FACTORY SET AND BONDED IN PLACE. THE SHIPPING NUT ON THE LIMIT BOLT MUST BE LOWERED UNTIL IT TOUCHES THE BOLT HEAD. THE NUT WAS SHIPPED IN THE RAISED POSITION. DO NOT ATTEMPT TO READJUST THE LIMIT BOLTS. FACTORY SETTING ASSURES UNIFORM BOLT LOADING IF UPLIFT OCCURS, AS IN THE CASE OF A COOLING TOWER BEING DRAINED. THE VMC GROUP RECOMMENDS BOLTING ALL ISOLATORS TO A **EQUIPMENT SUPPORT BEAM** FLAT SURFACE. WHEN A WEIGHT CHANGE OCCURS IN EXCESS OF 20% OF EQUIPMENT OPERATING WEIGHT. THE ISOLATOR BASE PLATE MUST BE BOLTED. THE LOAD MUST BE CENTERED ON THE -ADJUSTING NUT AND WASHER ISOLATOR TO AVOID ECCENTRIC LOADING OF TOP PLATE, WHICH REMOVABLE ADJUSTING BOLT (2 TYP) WOULD TILT THE TOP PLATE OF THE ISOLATOR. THE TOP PLATE OF (2 TYP) THE ISOLATOR MUST BE UNIFORMLY LOADED ACROSS ENTIRE LENGTH OF TOP PLATE OR THE EQUIPMENT MUST BE BLOCKED UNTIL LOAD IS TRANSFERRED TO THE ISOLATOR. THE VMC GROUP MUST BE ADVISED BEFORE THE ISOLATORS ARE RELEASED FOR PRODUCTION TO EVALUATE ANY VARIANCE TO THESE STEEL SHIM REQUIREMENTS. WHEN THE APPLICATION IS OUTDOORS AND THE EQUIPMENT WILL 3/8 GAP -BE SUBJECT TO HIGH WINDS, THE OWNER'S REPRESENTATIVE MUST EVALUATE ANCHOR TYPE AND SIZE TO EFFECTIVELY RESIST WIND FORCES. TYPE M2H ISOLATORS ARE NOT SUITABLE FOR SEISMIC APPLICATIONS. USE VMC GROUP TYPES MS ISOLATORS -SHIPPING NUT TO ISOLATE EQUIPMENT THAT WILL BE SUBJECT TO SEISMIC FORCES. -LIMIT-STOP BOLT ISOLATORS ARE SHIPPED TO THE JOB SITE WITH SHIMS BETWEEN THE TOP PLATE AND HOUSING. THESE SHIMS MUST BE IN PLACE WHEN ISOLATOR IS POSITIONED UNDER EQUIPMENT. THE ADJUSTMENT PROCESS CAN ONLY BEGIN AFTER FULL OPERATING WEIGHT IS REACHED. THE ADJUSTMENTS CAN BE MADE BY STARTING AT ANY ISOLATOR AND TURNING THE ADJUSTING NUT CLOCKWISE TWO TURNS. PROCEED AROUND THE EQUIPMENT TO EACH ISOLATOR, ADJUSTING EACH TWO TURNS TO COMPRESS THE SPRINGS UNIFORMLY. CONTINUE THIS ADJUSTING 3/4 DIA HOLE PROCESS UNTIL ONE ISOLATOR JUST RISES OFF THE SHIMS. (4 TYP) STOP ADJUSTMENT ON THAT AND OTHER ISOLATORS AS THEY RISE OFF THE SHIMS APPROXIMATELY 1/32". WHEN ALL ISOLATORS

HAVE RISEN ABOVE THE SHIMS, THE ADJUSTMENT PROCESS IS COMPLETE. REMOVE ALL SHIMS.

7. FURTHER ATTENTION TO THE INSTALLATION IS NOT NORMALLY REQUIRED. THE VMC GROUP SUGGESTS A SEMIANNUAL INSPECTION OF THE COMPONENTS FOR POSSIBLE CORROSION PROBLEMS. IF PROBLEMS ARE OBSERVED, CONSULT THE VMC GROUP OR CORROSION CONTROL EXPERTS TO RECTIFY THE PROBLEM.

8. IF THE SPRING PACKAGE MUST BE REMOVED. CONTACT A FACTORY REPRESENTATIVE FOR DETAILED PROCEDURE.

OTHER MATERIALS, COMPOUNDS, OR FINISHES WITH EQUAL OR SUPERIOR

CERTIFIED FOR:	
JOB NAME:	
CUSTOMER :	
CUSTOMER P.O.:	
SALES ORDER:	

MODEL M2H-5C 500-4600 LBS. SPRING ISOLATORS WITH INTERNAL ADJUSTMENT 5 INCH DEFLECTION



Houston, TX 77041

NONE SHEET:

REVISION