


	REV.	DESCRIPTION	DATE	BY
1				

TYPE M2H-5D SPRING ISOLATORS WITH INTERNAL ADJUSTME						
MODEL	MAX LOAD (LBS)	DEFLECTION (IN)	SPRING RATE (LB/IN)	SPRING COLOR CODE		
M2H-5D-5400	5400	4.63	1167	RED		
M2H-5D-5960	5960	4.47	1333	GREEN		
M2H-5D-7670	7670	4.60	1667	LT IVORY		
M2H-5D-9100N ¹	9100	4.63	1966	RED/BLACK		
M2H-5D-9530N ¹	9530	4.47	2134	GREEN/BLACK		
M2H-5D-11350N ¹	11350	4.60	2466	LT IVORY/BLACK		

NOTES:

1. TWO NESTED SPRINGS YIELD THIS LOAD. THE COLOR CODE IS FOR OUTER SPRING/ INNER SPRING



-BOLT AND WELD EQUIPMENT SUPPORT BEAM TO MOUNT (BY OTHERS, NOT SHOWN IN OTHER VIEWS FOR CLARITY)

> - STEEL SHIM (4 TYP) (REMOVE AFTER SPRING ADJUSTMENT) (SHIM ON FAR SIDE NOT SHOWN FOR CLARITY)

> > 1 SET OF (4) M2H-5D-11350N HDG SPRINGS REQ'D

TAG: CT

(1) (3) (5) (7)

(2) (4) (6) (8)

ISOLATOR SELECTIONS			
LOC 1:	LOC 2:		
LOC 3:	LOC 4:		
LOC 5:	LOC 6:		
LOC 7:	LOC 8:		
CUSTOMER EQP'T. TAG:			

NOTE: MATERIAL SHOWN IS FOR (1) SET.

ALL DIMENSIONS ARE IN INCHES. INTERPRET PER ANSI Y14.

- 2. UNLESS OTHERWISE NOTED, DIMENSIONS FOR STYLE APPLY TO ALL OTHER STYLES.
- 3. FINISH: HOUSINGS- POWDER COAT, SPRINGS- POWDER COAT, HARDWARE- ZINC ELECTROPLATE.
- 4. REFER TO SHEET 2 OF 2 FOR INSTALLATION INSTRUCTIONS.
- 5. INNER SPRING (WHEN USED) NOT SHOWN.

AEDTIEIED EAG

- 6. ALL SPRINGS ARE DESIGNED WITH 50% OVER TRAVEL.
- 7. SPRING PACKAGE MAY BE REMOVED WITH SHIMS IN PLACE. CONTACT A FACTORY REPRESENTATIVE FOR SPRING REMOVAL INSTRUCTIONS.
- 8. DIMENSIONS APPLY TO BOTH TOP BOLT DOWN AND BASE PLATE ANCHORING HOLE.
- 9. RATED DEFLECTIONS ARE WITHIN 25% OF NOMINAL. HIGHER DEFLECTIONS ARE ALLOWED IF THEY MEET SPECIFICATIONS

OTHER MATERIALS, COMPOUNDS, OR FINISHES WITH EQUAL OR SUPERIOR PROPERTIES MAY BE SUBSTITUTED AS THEY BECOME AVAILABLE.

CERTIFIED FOR:		
JOB NAME:		
CUSTOMER :		
CUSTOMER P.O.:		
SALES ORDER:		

MODEL M2H-5D 5400-11350 LBS. SPRING ISOLATORS WITH INTERNAL ADJUSTMENT 5 INCH DEFLECTION

THO EXTES MAT BE SUBSTITUTED AS THE TREGOME AVAILABLE.						
		SCALE:				
		NONE	Member			
		SHEET:		EMA		
	THE VMC GROUP	DRAWING NO.:		REVISION		
	The Power of Together					
	Bloomingdale, NJ 07403					
	Houston, TX 77041					

120R-101800 REV.: 6 REV. DESCRIPTION DATE BY READ INSTRUCTIONS IN THEIR ENTIRETY BEFORE BEGINNING. 1. LOCATE ISOLATORS UNDER EQUIPMENT AFTER DETERMINING POSITIONS DESIGNATED IN THE VMC GROUP SUBMITTAL. SHEET 1. 2. ALL LIMIT BOLTS ARE FACTORY SET AND BONDED IN PLACE. THE SHIPPING NUT ON THE LIMIT BOLT MUST BE LOWERED UNTIL IT TOUCHES THE BOLT HEAD. THE NUT WAS SHIPPED IN THE RAISED POSITION. DO NOT ATTEMPT TO READJUST THE LIMIT BOLTS. FACTORY SETTING ASSURES UNIFORM BOLT LOADING IF UPLIFT OCCURS, AS IN THE CASE OF A COOLING TOWER BEING DRAINED. THE VMC GROUP RECOMMENDS BOLTING ALL ISOLATORS TO A -EQUIPMENT SUPPORT BEAM FLAT SURFACE. WHEN A WEIGHT CHANGE OCCURS IN EXCESS OF 20% OF EQUIPMENT OPERATING WEIGHT. THE ISOLATOR BASE PLATE MUST BE BOLTED. THE LOAD MUST BE CENTERED ON THE ISOLATOR TO AVOID ECCENTRIC LOADING OF TOP PLATE, WHICH ADJUSTING NUT AND WASHER WOULD TILT THE TOP PLATE OF THE ISOLATOR. THE TOP PLATE OF REMOVABLE ADJUSTING BOLT (2 TYP) THE ISOLATOR MUST BE UNIFORMLY LOADED ACROSS ENTIRE (2 TYP) LENGTH OF TOP PLATE OR THE EQUIPMENT MUST BE BLOCKED UNTIL LOAD IS TRANSFERRED TO THE ISOLATOR. THE VMC GROUP MUST BE ADVISED BEFORE THE ISOLATORS ARE RELEASED FOR PRODUCTION TO EVALUATE ANY VARIANCE TO THESE STEEL SHIM REQUIREMENTS. WHEN THE APPLICATION IS OUTDOORS AND THE EQUIPMENT WILL 3/8 OPERATING **ELASTOMERIC** BE SUBJECT TO HIGH WINDS, THE OWNER'S REPRESENTATIVE GAP MUST EVALUATE ANCHOR TYPE AND SIZE TO EFFECTIVELY RESIST **SNUBBER** WIND FORCES. TYPE M2P ISOLATORS ARE NOT SUITABLE FOR SEISMIC APPLICATIONS. USE VMC GROUP TYPES MS ISOLATORS TO ISOLATE EQUIPMENT THAT WILL BE SUBJECT TO SEISMIC SHIPPING NUT FORCES. ISOLATORS ARE SHIPPED TO THE JOB SITE WITH SHIMS BETWEEN LIMIT-STOP BOLT THE TOP PLATE AND HOUSING. THESE SHIMS MUST BE IN PLACE WHEN ISOLATOR IS POSITIONED UNDER EQUIPMENT. THE ADJUSTMENT PROCESS CAN ONLY BEGIN AFTER FULL OPERATING WEIGHT IS REACHED. THE ADJUSTMENTS CAN BE MADE BY STARTING AT ANY ISOLATOR AND TURNING THE ADJUSTING NUT CLOCKWISE TWO TURNS. PROCEED AROUND THE EQUIPMENT TO EACH ISOLATOR, ADJUSTING EACH TWO TURNS TO COMPRESS THE SPRINGS UNIFORMLY. CONTINUE THIS ADJUSTING PROCESS UNTIL ONE ISOLATOR JUST RISES OFF THE SHIMS. STOP ADJUSTMENT ON THAT AND OTHER ISOLATORS AS THEY RISE OFF THE SHIMS APPROXIMATELY 1/32". WHEN ALL ISOLATORS HAVE RISEN ABOVE THE SHIMS, THE ADJUSTMENT PROCESS IS COMPLETE. REMOVE ALL SHIMS. 7. FURTHER ATTENTION TO THE INSTALLATION IS NOT NORMALLY REQUIRED. THE VMC GROUP SUGGESTS A SEMIANNUAL INSPECTION OF THE COMPONENTS FOR POSSIBLE CORROSION PROBLEMS. IF PROBLEMS ARE OBSERVED, CONSULT THE VMC GROUP OR CORROSION CONTROL EXPERTS TO RECTIFY THE PROBLEM. 8. IF THE SPRING PACKAGE MUST BE REMOVED, CONTACT A FACTORY REPRESENTATIVE FOR DETAILED PROCEDURE. OTHER MATERIALS, COMPOUNDS, OR FINISHES WITH EQUAL OR SUPERIOR PROPERTIES MAY BE SUBSTITUTED AS THEY BECOME AVAILABLE

CERTIFIED FOR:

JOB NAME: _____

CUSTOMER P.O.:

SALES ORDER:

CUSTOMER:

MODEL M2H-5D 5400-11350 LBS.
SPRING ISOLATORS
WITH INTERNAL ADJUSTMENT
5 INCH DEFLECTION



NONE

Wemper

The Power of Together Bloomingdale, NJ 07403 Houston, TX 77041 DRAWING NO.:

REVISION

PROPRIETARY: EXCEPT AS OTHERWISE AGREED IN WRITING, THE INFORMATION AND DESIGN DISCLOSED HEREIN ARE THE PROPERTY OF THE VMC GROUP AND MUST NOT BE COPIED OR DISTRIBUTED OUTSIDE THE VMC GROUP EXCEPT TO AUTHORIZED PERSONS WITH A GENUINE NEED TO KNOW WHO BY THE USE HEREOF ACKNOWLEDGE THE VMC GROUP'S OWNERSHIP AND AGREE TO MAINTAIN THIS INFORMATION AND DESIGN IN STRICT CONFIDENCE